




Spreader for grass seed, fertiliser, road salt, lime etc..

ROTHO™ spreads easily and quickly out desired amount. The size of the holes and the turning speed determine how quickly the spreader becomes empty.

1. Fill up the spreader with desired amount of material for spreading.
2. If it is raining, put the lid on.
3. Set the opening of the spreading holes by twisting the bottom section until its holes are suitable for the material's grain size.
4. Spread out by holding ROTHO™ with your arm extended, and then turn the spreader back and forth.
5. Change arm at even intervals.



An easy-grip handle is included. The handle also facilitates the handling of ROTHO™



Set the holes at the bottom after grain size



Phone number: +46 470 331 00
Mail: info@v-plast.com
www.v-plast.com

Volume 4 L
Art.nr V 70010